

## **Technical data sheet**

### **Product specification – 4551-111**

#### **Tray liners**

- Ideal to absorb excess of condensates produced in sterilization.
- Double application: Inside trays with delicate instruments on top or as tray base, protecting its edges.

#### **Crepe paper**

- Crepe paper.
- Approx. weight: 60g/sq.m.
- Minimum absorption.
- White.
- Plastic bag + transport carton.

#### **Non-woven airlaid**

- Non-woven airlaid.
- Approx. weight: 80g/sq.m.
- High absorption capacity.
- White.
- Plastic bag + transport carton.